

NRAQ.E186098 - Programmable Controllers

Programmable Controllers

FATEK AUTOMATION CORP

26th Fl
29 Jungjeng E Rd Sec 2
Danshuei District
New Taipei, 251 Taiwan

E186098

Analog boards, Model(s): [FBs-B2A1D](#), [FBs-B2DA](#), [FBs-B4AD](#)

Analog expansion modules, Model(s): [FB-2DA](#), [FB-6AD](#), [FB-8AD](#), [FBs-2DA](#), [FBs-4A2D](#), [FBs-4DA](#), [FBs-6AD](#)

Analog with temperature expansion modules, Model(s): [FBs-2A4RTD](#), [FBs-2A4TC](#)

Angular Resolver Decoder Module, Model(s): [FBs-RZR](#)

Bluetooth to RS232 wireless data communication converter, Model(s): [FBs-B2C](#)

Communication boards, Model(s): [FBs-CB2](#), [FBs-CB22](#), [FBs-CB25](#), [FBs-CB5](#), [FBs-CB55](#), [FBs-CBCAN](#), [FBs-CBE](#), [FBs-CBEH](#)

Communication distributors, Model(s): [FB-DTBR](#), [FB-DTBR-E](#)

Communication modules, Model(s): [FBs-CM22](#), [FBs-CM25](#), [FBs-CM25C](#), [FBs-CM25E](#), [FBs-CM55](#), [FBs-CM55E](#), [FBs-CM5H](#), [FBs-CM5R](#)

Digital expansion I/O modules, Model(s): [FBs-16](#) followed by X, Y, XY or YT/J, may be followed by R, T or J

Digital expansion I/O modules, Model(s): [FBs-20](#) followed by X, Y, XY or YT/J, may be followed by R, T or J

Digital expansion I/O modules, Model(s): [FBs-24](#) followed by X, Y, XY or YT/J, may be followed by R, T or J

Digital expansion I/O modules, Model(s): [FBs-40](#) followed by X, Y, XY or YT/J, may be followed by R, T or J

Digital expansion I/O modules, Model(s): [FBs-60](#) followed by X, Y, XY or YT/J, may be followed by R, T or J

Digital expansion I/O modules, Model(s): [FBs-8](#) followed by X, Y, XY or YT/J, may be followed by R, T or J

Digital expansion I/O units, Model(s): [FBs-24XY](#) followed by R, T or J, followed by AC, D12 or D24

Digital expansion I/O units, Model(s): [FBs-40XY](#) followed by R, T or J, followed by AC, D12 or D24

Digital expansion I/O units, Model(s): [FBs-60XY](#) followed by R, T or J, followed by AC, D12 or D24

Digital expansion modules, Model(s): [FB-15EA](#), [FB-24EY](#), [FB-24EYP](#), [FB-28EA](#), [FB-28EAP](#), [FB-28EAT](#), [FB-32EX](#), [FB-40EA](#), [FB-40EAT](#), [FB-48EAT](#), [FB-48EX](#), [FB-48EYT](#), [FB-7EY](#), [FB-7SG1](#), [FB-7SG2](#), [FB-7SG3](#), [FB-8EA](#), [FB-8EAT](#), [FB-8EX](#), [FB-8EY](#), [FB-8EYT](#)

Expansion power supplies, Model(s): [FBs-EPW-AC](#), [FBs-EPW-D24](#)

Expansion units, Model(s): [FB-28EAPT](#), [FB-32EXP](#), [FB-40EAP](#), [FB-40EAPT](#)

Human Machine Interface, Model(s): [P5101NA](#), [P5101SA](#), [P5101ZA](#), [P5102S](#), [P5102N](#), and [P5102N1](#), [P5150NH](#)

Human Machine Interface, Model(s): [P5](#), followed by [070](#), followed by [S](#), [N](#), [N1](#), [SA](#), [NA](#) or [ZA](#)

Human Machine Interface, Model(s): [P5043NA](#) both may be followed with "A" for marketing purpose

Human Machine Interface, Model(s): P5043S and P5043N both may be followed with "A" or "B" for marketing purpose

Human Machine Interface, Model(s): P5043SA both may be followed with "A" for marketing purpose

LED display modules, Model(s): FBS-7SG1, FBS-7SG2

Left side analog expansion modules, Model(s): B1-L2A1D, followed by S or blank, B1-L2DA, followed by S or blank, B1-L4AD, followed by S or blank

Left Side Analog Expansion Modules, Model(s): B1-L2A2D, followed by S or blank, B1-L4NTC, followed by S or blank

Left side communication expansion modules, Model(s): B1-CM2, followed by S or blank, B1-CM22, followed by S or blank, B1-CM25, followed by S or blank, B1-CM25E, B1-CM5, followed by S or blank, B1-CM55, followed by S or blank, B1-CM55E

Load cell modules, Model(s): FBS-1HLC, FBS-1LC, FBS-2LC

Main units, Model(s): FBe-20MA, FBe-20MAT, FBe-20MC, FBe-20MCT, FBe-28MA, FBe-28MAT, FBe-28MC, FBe-28MCT, FBe-40MA, FBe-40MAT, FBe-40MC, FBe-40MCT, FBe-54MA, FBe-54MAT, FBe-54MC, FBe-54MCT, FBn-19MC, FBn-19MCT, FBn-26MCT, FBn-36MC, FBn-36MCT, FBnN-26MC

Main units, Model(s): B1 followed by -10M, 14M, 20M, 24M, 32M, or 40M, followed by R, J or T, followed by 2, U or 25, followed by -AC, D24 or D24S.

Main units, Model(s): B1z followed by -10M, 14M, 20M, 24M, 32M, or 40M, followed by R, J or T, followed by 2 or U, followed by -AC, D24 or D24S.

Main units, Model(s): HB1 followed by -10M, 14M, 20M, 24M, 32M, or 40M, followed by R, J, or T, followed by 5 or 25, followed by -D24S.

Potential meter modules, Model(s): FBS-4PT

Power supplies, Model(s): FB-EPOW

Programing Device, Model(s): FP-08

Programmable Controllers, Model(s): FBS-CBES

Programmable controllers, main units, Model(s): FBS-10MA followed by R, T or J, followed by 2, or U, followed by AC, D12, or D24, may be followed by C

Programmable controllers, main units, Model(s): FBS-10MC followed by R, T or J, followed by 2 or U, followed by AC, D12 or D24, may be followed by two extension numerals

Programmable controllers, main units, Model(s): FBS-14MA followed by R, T or J, followed by 2, or U, followed by AC, D12, or D24, may be followed by C

Programmable controllers, main units, Model(s): FBS-14MC followed by R, T or J, followed by 2 or U, followed by AC, D12 or D24, may be followed by two extension numerals

Programmable controllers, main units, Model(s): FBS-20MA followed by R, T or J, followed by 2, or U, followed by AC, D12, or D24, may be followed by C

Programmable controllers, main units, Model(s): FBS-20MC followed by R, T or J, followed by 2 or U, followed by AC, D12 or D24, may be followed by two extension numerals

Programmable controllers, main units, Model(s): FBS-20MN followed by R, T or J, followed by 2 or U, followed by AC, D12 or D24

Programmable controllers, main units, Model(s): FBS-24MA followed by R, T or J, followed by 2, or U, followed by AC, D12, or D24, may be followed by C

Programmable controllers, main units, Model(s): FBS-24MC followed by R, T or J, followed by 2 or U, followed by AC, D12 or D24, may be followed by two extension numerals

Programmable controllers, main units, Model(s): FBs-32MA followed by R, T or J, followed by 2, or U, followed by AC, D12, or D24, may be followed by C

Programmable controllers, main units, Model(s): FBs-32MB followed by R, T or J, followed by 2, or U, followed by AC, D12, or D24, may be followed by C

Programmable controllers, main units, Model(s): FBs-32MC followed by R, T or J, followed by 2 or U, followed by AC, D12 or D24, may be followed by two extension numerals

Programmable controllers, main units, Model(s): FBs-32MN followed by R, T or J, followed by 2 or U, followed by AC, D12 or D24

Programmable controllers, main units, Model(s): FBs-40MA followed by R, T or J, followed by 2, or U, followed by AC, D12, or D24, may be followed by C

Programmable controllers, main units, Model(s): FBs-40MB followed by R, T or J, followed by 2, or U, followed by AC, D12, or D24, may be followed by C

Programmable controllers, main units, Model(s): FBs-40MC followed by R, T or J, followed by 2 or U, followed by AC, D12 or D24, may be followed by two extension numerals

Programmable controllers, main units, Model(s): FBs-44MN followed by R, T or J, followed by 2 or U, followed by AC, D12 or D24

Programmable controllers, main units, Model(s): FBs-60MA followed by R, T or J, followed by 2, or U, followed by AC, D12, or D24, may be followed by C

Programmable controllers, main units, Model(s): FBs-60MB followed by R, T or J, followed by 2, or U, followed by AC, D12, or D24, may be followed by C

Programmable controllers, main units, Model(s): FBs-60MC followed by R, T or J, followed by 2 or U, followed by AC, D12 or D24, may be followed by two extension numerals

Programmable memory packs, Model(s): FBs-Pack

PWMDA module, Model(s): PWMDA

Right side digital expansion modules, Model(s): B1-16X, B1-16XS, B1-8X, B1-8XS

Right side digital expansion modules, Model(s): B1-16XY followed by R, T or J, followed by S or blank

Right side digital expansion modules, Model(s): B1-16Y followed by R, T or J, followed by S or blank

Right side digital expansion modules, Model(s): B1-24XY followed by R, T or J, followed by S or blank

Right side digital expansion modules, Model(s): B1-40XY followed by R, T or J, followed by S or blank

Right side digital expansion modules, Model(s): B1-8XY followed by R, T or J, followed by S or blank

Right side digital expansion modules, Model(s): B1-8Y followed by R, T or J, followed by S or blank

Simple man-machine interfaces (MMI), Model(s): FB-DAP-A, FB-DAP-B, FBs-BDAP, FBsBPEP, FBs-DAP-B/BR, FBs-DAP-C/CR, FBs-PEP

Switch input modules, Model(s): FBs-32DGI

Switching Power Supply, Model(s): ADP-13.8V-8A

Synchronous Serial Interface Module/Board, Model(s): FBs-3SSI, FBs-BSSI

Temperature expansion modules, Model(s): FB-2AH4, FB-2AJ4, FB-2AK4, FB-2AT4, FB-4AJ12, FB-4AJ18, FB-4AJ24, FB-4AK12, FB-4AK18, FB-4AK24, FBs-16RTD, FBs-16TC, FBs-2TC, FBs-6NTC, FBs-6RTD, FBs-6TC

Voice modules, Model(s): FBs-VOM

在此資料庫中出現的公司名稱或產品，並不代表其產品本身的製造有經過UL 後續檢驗服務的把關。僅有附 UL 標誌的產品才可被視為取得認證，並涵蓋在UL 後續檢驗服務範疇裡。請務必確認產品上是否有此標誌。

UL 允許複製線上認證目錄中所包含的資料，但必須符合以下條件：1.指南資訊、零組件、構造、設計、系統和/或認證 (檔案) 必須以完整的方式呈現，且不得誤導、不得操弄這些資料 (或圖繪)。2.「經 UL 許可自線上認證目錄轉載」的聲明，必須顯示在擷取的資料旁。此外，轉載的資料必須包含以下格式的版權聲明： "© 2022 UL LLC"